#### Intro



#### **ADA Operations Contact Info**

Todd Grugel ph: 651-366-3531 email: todd.grugel@state.mn.us

Joe Zilka ph: 651-366-3311 email: joseph.zilka@state.mn.us

Harvey Unruh ph: 651-216-2912 email: harvey.unruh@state.mn.us

http://www.dot.state.mn.us/ada/construction.html

Your Destination...Our Priority



















#### **MnDOT ADA Training**

# (1803) PROSECUTION OF WORK SPECIAL PROJECT ADA REQUIREMENTS

Your Destination...Our Priority

















#### **ADA & PROWAG**



- Congress passed the Americans with Disabilities Act (ADA) in 1990.
- U.S. Access Board's Public Rights-of-Way Accessibility Guidelines (PROWAG) issued in 2005
- ADA building regulations revised in 2010, effective March 2012
- All pedestrian facilities and shared use trails within MnDOT right-of-way must be constructed according to PROWAG (as of February 2010) and the 2010 ADA Standards.

#### 1803 Special Provision Highlights



- The appropriate pedestrian ramp details for each quadrant are included in the plans. The Engineer may provide additional details to those provided in the plans that meet the PROWAG guidelines as the need arises and field conditions dictate.
- The contractor must designate a RESPONSIBLE person competent in all aspects of PROWAG to assess proposed sidewalk layouts at each site before work begins.
- Any time work the contractor is performing concerns pedestrian facilities, the contractor's RESPONSIBLE person shall be on site.

## Pedestrian Access Route (PAR)



 Pedestrian Access Route must be constructed to meet the following criteria:



# (1) PAR



- Minimum 4 ft. wide Pedestrian Access Route (PAR)
- Maximum cross slope of 2%



#### (1) PAR



 Vertical discontinuities (bumps) must be less than 0.25 inches.

Must provide positive drainage without

allowing any ponding





## (1) PAR



 All grade breaks within the PAR shall be constructed perpendicular to the path of travel.





 Landings are part of the PAR and must be constructed to meet the following criteria:





• 4 feet by 4 feet minimum width.





• Maximum slope of 2% in all directions.






- Required at all locations where the PAR changes directions or inverse grades.
- Must be connected to the PAR.



#### (3) Ramps



 Longitudinal slopes less than 5% in the direction of travel require no landing at the top of the ramp (unless the PAR changes direction).





## (3) Ramps



 Longitudinal slopes between 5% and 8.3% in the direction of travel require a landing at the top of the ramp and at a change of direction.



#### " Hold Points"



- If the Contractor constructs any pedestrian or shared-use facilities that are not per plan, do not meet the above requirements, or do not follow the agreed upon resolution, the Contractor will be responsible for correcting the deficient facilities with no compensation paid for the corrective work.
- To ensure that the pedestrian facilities are constructed in compliance with PROWAG, the contractor shall follow the following three steps:

#### Step (1) Removals



- The Contractor shall use the appropriate ramp details in the plan and identify the removal limits for the sidewalk and curb and gutter. If the contractor determines the removal limits are not adequate to meet PROWAG, the Contractor shall stop work immediately on that quadrant and consult the Engineer to determine the best solution.
- (If the Contractor and Inspector are actively working together at the beginning of the project most issues should be resolved quickly).

#### Determine the best solutions




- 4 Steps to help in determining the best solutions:
- 1. Check Your construction plan sheets including notes and tabulations.
- 2. Check Standard Plans find Curb Ramp type and notes that provide additional direction.
- 3. Check Special Provisions 1803 and any ADA pay items and follow construction requirements.
- 4. Consult your Engineer first and if additional guidance is needed contact ADA office.

## Step (1) Removals



 Once the Engineer and the Contractor reach agreement on how to proceed, the Contractor may finish the removals.



## Step (2) Curb and Gutter



- Verify the zero height curb and curb transitions and will be located as shown in the plans and will provide an adequate detectable edge as shown Standard Plans (sheet 4 of 5).
- Verify that proposed curb flow line will provide positive drainage as well as maintain existing gutter inflows/outflows.
- The curb and gutter shall be constructed as detailed in the Plan with a defined flow line.
- The Contractor shall consult with the Engineer to determine a resolution if any of these conditions cannot be met.

# Step (2) Curb and Gutter



 Spec. 2531Concrete Curb and Gutter ADA: if gutter flow line exceeds 2% The flow line should be adjusted to allow a flatter slope, but still provide positive drainage.



#### Step (3) Landings and Ramps



 After the curb and gutter has been correctly poured and the contractor has set the sidewalk forms and prior to placing the concrete curb ramps/sidewalk:



#### Step (3) Landings and Ramps





- The Contractor shall verify the slope requirements will be achieved.
- If any requirements cannot be met, the Contractor shall meet with the Engineer to determine the best solution.

#### **Setting Forms**




In addition, the longitudinal slopes shown in the Construction Plans and the Standard Plans shall be utilized unless these conditions cannot be met. The starting point for setting the forms on the controlling ramp leg should be the following:

Steep (S) = 
$$7\%$$
  
Flat (F) =  $4\%$   
Landing =  $1.5\%$   
Sidewalk Cross Slope =  $1.5\%$   
Fan ramp =  $4\%$ 

#### (C) Layout Responsibilities




If specific dimensions are not provided in the plan, the contractor shall be expected to scale dimensions from the plan.



## (C) Layout Responsibilities




 If contractor surveying is not called for in the plans, the owner's surveyor will only stake points and elevations provided in the plans.



#### (D) Contractor Responsibilities



 The Contractor shall utilize measures and methods when working near existing buildings and or private landscaping that will avoid damaging the buildings face or structure or other private property.





• The Contractor shall round all joints and edges of the walk with a ¼ inch radius edging tool.





Contraction joints shall extend to at least 30% of sidewalk thickness. If saw cutting provide <sup>1</sup>/<sub>8</sub> inch wide contraction joint as per MnDOT 2521





The contractor shall also have the option of providing saw cuts to construct the sidewalk joints.





This work shall be considered incidental with no extra compensation paid.



 The top grade break of walkable flares need a visual joint to indicate a change in grade. This visual joint shall meet Spec. 2521.3D except the depth requirement is reduced to 1/4"






 Where sidewalk is constructed around fixed structures and the grade has been changed, the sidewalk shall be finished around these structures to the satisfaction of the Engineer at no additional cost.





 Variable height concrete foundation repair detail on web site.





Push buttons face towards the intersection and parallel to outside edge of crosswalk.





Push buttons shall be minimum 4' maximum 10' from back edge of curb( 1.5' to 4' if mounted on signal pole as indicated in plan or as approved by Engineer.





At rural locations without curb and gutter it is recommended APS push buttons be set back 8 ft. from edge of roadway for preservation purposes.





Shall be offset no more than 5 ft. from projected outside edge of crosswalk/domes






Shall be offset no more than 5 ft. from projected outside edge of crosswalk / domes.





Push buttons shall be a minimum 10 ft. apart, except in islands and medians then provide 6 ft. minimum clear distance.





4' x 4' minimum landing immediately adjacent with 2% max slope in all directions





Center the push button on the landing if possible with out violating any other Special Provision. The landing must be connected to the PAR





Provide 6 ft. clear distance between obstructions whenever possible for MAR (maintenance access route).





All new hand holes shall be placed outside the PAR, Inclusive (Including) of ramps and

landings.





The push button shall be mounted at a height of 42 inches, (have 10 inch maximum side reach, and 7 ft. minimum overhead sign clearance).





Crosswalks shall be striped in a straight alignment between the outside edges of detectable warnings with no kinks unless shown as kinked in the plan.





Crosswalks shall be striped in a straight at the outside edge of the detectable warnings.






The Contractor shall maintain all working points and use them for push button layout.



#### **NEW for all APS 2014**




New Breakaway Pedestal Base Push Button Station







#### **APS Push Button Station and Location**



- THE PUSH BUTTON STATION FOUNDATION IS CONSTRUCTED AS PART OF THE SIDEWALK. INCREASE THE SIDEWALK THICKNESS TO 12" THICK (MIN.) TO PROVIDE FOR THE PUSH BUTTON STATION FOUNDATION.
- (2) ALL JOINTS SHALL BE A MINIMUM OF 9" FROM THE CENTER OF THE PUSH BUTTON FOUNDATION.



#### APS Push Button Station and Location





- 1 THE PUSH BUTTON STATION FOUNDATION IS CONSTRUCTED AS PART OF THE SIDEWALK. INCREASE THE SIDEWALK THICKNESS TO 12" THICK (MIN.) TO PROVIDE FOR THE PUSH BUTTON STATION FOUNDATION.
- (2) ALL JOINTS SHALL BE A MINIMUM OF 9" FROM THE CENTER OF THE PUSH BUTTON FOUNDATION.



#### **APS Push Button Station and Location**






- 1 THE PUSH BUTTON STATION FOUNDATION IS CONSTRUCTED AS PART OF THE SIDEWALK. INCREASE THE SIDEWALK THICKNESS TO 12" THICK (MIN.) TO PROVIDE FOR THE PUSH BUTTON STATION FOUNDATION.
- (2) ALL JOINTS SHALL BE A MINIMUM OF 9" FROM THE CENTER OF THE PUSH BUTTON FOUNDATION.

# **Typical APS Push Button Location**








## **Typical APS Push Button Location**





#### REQUIREMENTS FOR LOCATING APS PUSH BUTTONS\*


- THIS IS A GENERAL DETAIL INTENDED TO SHOW THE REGISTEMENTS OF APS PUSH BUITTON LOCATION. FOR PHOLECT SPECIFIC DETAILS REGISTEDING PEDESTRIAN RAMP LAYOUT, SEE THE PEDESTRIAN CURB RAMP AND SIDEMALK DETAILS.
- THE FACE OF THE BUTTON SHALL BE PARALLEL WITH THE OUTSIDE EDGE OF CROSSBALK.
- A MINIMUM 4 FT X 4 FT LANDING AREA SHALL BE PROVIDED ADJACENT TO EACH BUTTON, WITH A 2 PERCENT MAXIMUM SLOPE IN ALL DIRECTIONS.
- BUTTONS SHALL BE WITHIN 5 FT OF THE OUTSIDE EDGE OF THE CROSSWALK.
- BUTTONS SHALL BE BETWEEN 1.5 FT AND 10 FT FROM THI BACK OF CURB OR EDGE OF ROADBAY, BEASURED IN THE DIRECTION OF TRANSL. STRADALONE PUSH BUILTON STATIONS SHOULD BE 4 MINIMAM FROM THE BACK OF CURB TO AVYOR KNOCKLOWNS.
- BUTTONS SHALL BE AT LEAST 10 FT APART.




SIGNAL CONTROL POINTS SIGNAL NO. X Y			DISTANCE_TO	DISTANCE TO
SIGNAL NO.	×	Y	LANGTHS (FT)	LANDTHO (FT)
P82-1	-	-	Α	В
PB4-2	-		0	D

- A DISTANCE MEASURED FROM THE PUSH BUTTON TO THE FRONT OF LANDING/TOP OF RAMP
- B CLEAR DISTANCE MEASURED FROM THE PUSH BUTTON TO THE BACK OF LANDENG/EDGE OF WALK
- C CLEAR DISTANCE MEASURED FROM THE PUSH BUTTON TO THE OUTSIDE EDGE OF DOMES IN THE DIRECTION OF TRAVEL
- D CLEAR DISTANCE FROM THE PUSH BUTTON TO THE BACK OF LANDING MEASURED IN THE OPPOSITE DIRECTION OF TRAVEL
- 1 BUTTON SHOULD BE 2 FT WINIMUM FROM RAMP GRADE BREAK AND BACK OF MALK.
- PROVIDE A MAINTENANCE ACCESS ROUTE (MAR) WHEREVER POSSIBLE FOR SHOW REMOVAL PURPOSES, A MAR REQUIRES A 6 FF MINIMUM CLEAR DISTANCE BETWEEN A PUSH BUTTON AND ANY CONSTRUCTIONS, INCLUDING BUILDINGS, V-CUBB, ELECTRICAL POUNDATIONS, SIGNAL CADINETS, OR ANOTHER PUSH BUTTON.

TYPICAL APS PEDESTRIAN PUSH BUTTON LOCATION










Signal pole Foundations: The APS push button shall meet the vertical horizontal and crosswalk skew requirements.

## MnDOT APS Pole Mounting Adaptor























#### **MnDOT Pedestal Foundation**



New Pedestal Foundations shall be constructed flush to within 1/4" of Landing.





















### **MnDOT Pedestal Foundation**



New Pedestal Foundations shall be constructed flush to within 1/4" of Landing.



















## "Saddle Adaptors" on Pedestals



Used on existing pedestal poles.





# **Questions?**





**ADA Training** 

Your Destination...Our Priority















